


# STUDIO

TYPE-1  
LEVEL: 15



LEVEL: 15

# STUDIO

TYPE-2  
LEVEL: 15



LEVEL: 15

# STUDIO

TYPE-3  
LEVELS: 17-18




LEVELS: 17,18

# STUDIO

TYPE-4  
LEVELS: 23-36 & 49-58



LEVELS: 23,24,25,26,27,28,29,30,31,  
32,33,34,35,36



LEVELS: 49,50,51,52,53,54,55,56,57,58

# STUDIO


TYPE-5  
LEVELS: 46, 70 & 72



LEVELS: 46, 70 & 72

# STUDIO

TYPE-7  
LEVELS: 48-58



LEVELS: 48,49,50,51,52,53,54,55,56,57,58

# STUDIO

TYPE-8  
LEVELS: 49-50



LEVELS: 49,50

# STUDIO

TYPE-9  
LEVELS: 52-58



LEVELS: 52,53,54,55,56,57,58

# STUDIO


TYPE-10  
LEVEL: 70



LEVEL: 70

# STUDIO


TYPE-12  
LEVELS: 45 & 71



LEVELS: 45 & 71

# STUDIO


TYPE-13  
LEVEL: 19



LEVEL: 19

# 1 BEDROOM


TYPE-1  
LEVELS: 11, 12-14, 15-30, 31-36,  
38-58 & 67-72




LEVEL: 11




LEVELS: 12,13,14




LEVELS: 15,16,17,18,19,20,21,22,23,  
24,25,26,27,28,29,30



LEVELS: 31,32,33,34,35,36



LEVELS: 38,39,40,41,42,43,44,45,46,47,48,  
49,50,51,52,53,54,55,56,57,58



LEVELS: 67,68,69,70,71,72